


GPS - 502 CGA - VGA & SXGA CONVERTER FOR CRT and LCD display monitor



SW 1	1	2	3	4	5	6	7
VGA	X	X	X	X	X	X	X
SVGA	X	O	O	← contrary color (色相反)			
XGA	O	X					
SXGA	O	O					



SW. 2 (Mode Adjust)- Set A/B/C/D mode from LED flash speed
(調整畫面) 由LED閃爍速度區分，可設定 A.B.C.D 四種模式

MODE	LED SPEED	SW - 3	SW - 4
A	慢 SLOW	1	move to left (左移)
B		2	H. larger (水平大)
C		3	up (上移)
D	快 QUICK	4	V. larger (垂直大)

SW.5 (ENTER)

Adjust OK Press SW.5 to save , turn off then turn on
調整OK 按 SW.5 儲存，重開機可固定信號模式